

# CRISP<sup>n</sup>BAKE

## Air Fry Toaster Oven

# AIR FRY

- 1 Place food on Air Fry mesh rack in a single layer.
- 2 Open door and slide Air Fry mesh rack with food into the middle rack position.
- 3 Set Function selector knob to AIR FRY position.
- 4 Turn TIMER selector knob to 20 and then turn to desired Air Frying time or select 'Stay On' to air fry longer than 60 minutes or to control cooking time yourself.
- 5 Open the oven door. Using oven mitts or pot holders, slide the rack out to remove the cooked food.

**BLACK+DECKER**

FOOD	COOK TIME*
<i>Frozen Snack Food</i>	
Chicken Nuggets	13-16 min. or until crisp and golden brown
Chicken Strips	25-28 min. or until crisp and golden brown
Fish Sticks	10-12 min. or until crisp and golden brown
Breaded Onion Rings	10-12 min. or until breading is crisp
Breaded Mushrooms	16-20 min. or until breading is crisp
Mozzarella Sticks	10-12 min. or until breading is crisp
Jalapeño Poppers	14-16 min. or until breading is crisp
Corn Dogs	23-25 min. if frozen. Rotate front to back halfway through cooking.
Potato Skins	13-15 min. or until hot and cheese is melted
<i>Potatoes &amp; Fries</i>	
Straight or Crinkle Cut Fries (Frozen)	20-25 min. or until golden brown
Thick Steak Fries (Frozen)	18-24 min. or until golden brown
Thin Shoestring Fries (Frozen)	14-18 min. or until golden brown
Potato Wedge/Fries (Fresh)	20-25 min. or until golden brown
Seasoned Potato Nuggets	20-25 min. or until golden brown
<i>Meat &amp; Poultry</i>	
Chicken Wings	12-15 min. or until hot
Chicken Drumsticks	20-30 min. or until internal temp is 165°F / 75°C

\* **Note:** For these and other foods, please review manufacturer suggested cook times.

© 2018 The Black & Decker Corporation and Spectrum Brands, Inc.  
BLACK+DECKER and the BLACK+DECKER logo are trademarks of The Black & Decker Corporation and are used under license.  
All rights reserved.